

**Low-pass filter coils**



L1 and L2, 28 turns



L3 and L4, 19 turns



L5 and L6, 15 turns



L7 and L8, 11 turns



L9 and L10, 10 turns



L11 and L12, 8 turns

Red toroidal cores Amidon T-50-2  
Yellow toroidal cores Amidon T-50-6  
Enamel copper wire, diameter 0.6 mm (AVG22)  
Approx wire length 25 mm per turn

**SWR transformer coils**



T1 and T2, 25 turns

Amidon toroidal core (color black) FT-37-61 in Rev A and FT-50-61 in Rev B  
Enamel copper wire, diameter 0.4 mm (AVG26)  
Approx wire length 25 mm per turn

Add one turn of tinned copper through the core when installing the SWR coils on the board. See pictures.